

PC LAP COUNTER 5.48i

TASTENKOMBINATIONEN

Key	Action
1 to 9	Simulate lap on lane 1 to 9
0	Simulate lap on lane 10
F1 to F12	Simulate lap on lane 11 to 22
SHIFT + Lane / Car N°	Subtract a lap
CTRL + Lane / Car N°	Apply/Cancel Stop & Go Penalty
ALT GR + Lane / Car N°	Simulate a PIT IN / PIT OUT
ENTER	Start/Pause/Restart the race
INSERT, DELETE or CTRL + U	Open the update window
PAUSE , SPACE BAR or ALT + F2	Pause the race
ALT + M	Display - Hide the messages part
ALT + B	Display - Hide the best time part
ALT + F1	Start the race
ALT + F3	Resume the race
ALT + F4	Quit Pc Lap Counter
ALT + F5	Stop the race
ALT + F6	Start a count down
CTRL + B	Update the driver best laptime (of the driver having the focus in the best time part of PCLC)
CTRL + D	View driver Lap detail (of the driver having the focus in the best time part of PCLC)
CTRL + G	Open/Close the ghost cars speed window
CTRL + H	View the heat data
CTRL + I	Programming cars (only with Scalextric C7042)
CTRL + L	Open the live timing leader board in your browser
CTRL + M	Make the drivers rotation
CTRL + N	Configure a new race
CTRL + O	Open a race
CTRL + P	Open the report menu
CTRL + R	Clear all drivers best laptime
CTRL + S	Save the race
CTRL + Y	Start/Stop Yellow Flag
Main screen classement: double click on driver,team,car columns	open the update window
Main screen classement: double click on the lap column	open the lap detail window
Main screen classement: double click on the best lap time column	reset the best lap time
Main screen: click on the record lap time	open the update best lap time window
Main screen best time: double click	open the update best lap time window